



Crown Settings

Unscrew crown to access settings / screw crown for normal running

- I. Hand-winding (30 turns to fully wind the watch)
- II. Change date
- III. Set time and stop second hand